

AMINO SET TOP BOX (STB) PARENTAL CONTROL SETTING INSTRUCTIONS

TO ACCESS THE PARENTAL CONTROL SETTINGS

1. Click the MENU button on the remote control
2. Use the arrow key on the remote to arrow down to SETTINGS and click OK on your remote
3. Arrow down to PARENTAL and click OK

TO CHANGE YOUR PIN NUMBER

FOLLOW STEPS 1-3 ABOVE TO ACCESS THE PARENTAL CONTROL SETTINGS

- Select CHANGE PIN (0000 is the default PIN that your STB box is set up with from Otelco)
- Change the PIN for both RATINGS and PURCHASES (PIN must be 4 numbers)
- If you have previously changed your PIN and have forgotten it, contact the business office for assistance

TO BLOCK/UNBLOCK CHANNELS

FOLLOW STEPS 1-3 ABOVE TO ACCESS THE PARENTAL CONTROL SETTINGS

- Select EDIT LOCKED
- Use the up/down arrow keys to search for the channels you wish to lock
- Press OK to place a checkmark next to the channel you want to lock
- Press the BLUE button on your remote to save your changes or press the RED button to discard your changes
- To block locked channels from the guide follow the steps below in BLOCKING RATED AND/OR LOCKED CHANNELS.
-

TO SET RATINGS

FOLLOW STEPS 1-3 ABOVE TO ACCESS THE PARENTAL CONTROL SETTINGS

- Select SET RATINGS
- Use the arrow key to select ratings you wish to block
- Click OK
- Titles of rated shows will still show but you will be unable to view the shows without entering your PIN. To block the titles follow the steps below in BLOCKING RATED AND/OR LOCKED CHANNELS.

TO BLOCK RATED AND/OR LOCKED CHANNELS

FOLLOW STEPS 1-3 ABOVE TO ACCESS THE PARENTAL CONTROL SETTINGS

- Select OPTIONS (requires PIN to change)
- Use the arrow key to choose whether or not you want to show restricted and locked channels
- Click OK

TO SET TIME RESTRICTIONS

FOLLOW STEPS 1-3 ABOVE TO ACCESS THE PARENTAL CONTROL SETTINGS

- Select TIME RESTRICTIONS (requires PIN to change)
- This option will allow you to set restrictions by the hour for each day
- Press the GREEN button on your remote to choose the time(s) of day you would like to block programming
- To remove or edit blocked programming, press the RED button on the remote
- Press the EXIT button on your remote to save your changes.

CANCEL OVERRIDE

FOLLOW STEPS 1-3 ABOVE TO ACCESS THE PARENTAL CONTROL SETTINGS

- Select CANCEL OVERRIDE
- This allows you to cancel all restrictions (requires PIN to cancel)